

LIL
matey
✠ PIRATFRAMES ✠



NOTICE

INSTALL YOUR PRESSNUTS USING BOTTOM PLATE AND A SCREW



**GOLD
10MM**

**BLACK
12MM**

**BLACK
10MM**

**BLACK
8MM**

**PRESS
NUT**

INSTALL THE 12MM SCREWS UP TO THE SPACERS



**GOLD
10MM**



**BLACK
12MM**



**BLACK
10MM**



**BLACK
8MM**



**PRESS
NUT**

INSTALL THE 10MM SCREWS TO THE PRESSNUTS AND SPACERS



- | | | | | |
|---|---|---|---|--|
|  |  |  |  |  |
| GOLD
10MM | BLACK
12MM | BLACK
10MM | BLACK
8MM | PRESS
NUT |

INSTALL THE GOLD AND 8MM SCREWS ON THE TOP PLATE

