PUNCH&SHORTY

ASSEMBLY

WASHER	16MM	12MM	10MM	8MM	8MM BUTTON	1.6/8MM

LET'S BUILD THIS PRECIOUS!

16MM
SCREW

BOTTOM PLATE

# CHOOSE YOUR GEOMETRY BY ROTATING ARMS

SQUISHED

TRUE X

SORRY
because of the tightness
this step can be painful

INSTALL THE MIDDLE PLATE

we encourage you to remove the stack's pressnuts you'll not use
to avoid contact with your esc components

**12MM
SCREW**

# SCREW TO TIGHTEN ALL

8MM BUTTON HEAD SCREW

TIPS
Screw each screw a little at a time.
You don't need to tighten them untill you've screwed down the top plate

INSTALL THE CAM CAGE

12MM   8MM

Take a 12mm and a 8mm screw.
place the cage, protuberance down,
reinforcement inwards.

Screw in the 8mm screw at the rear.
Screw in the 12mm screw at the front,
stopping before it protrudes inside the
cage.

Place the tpu holder.
Screw in the 12mm screw while
holding the tpu firmly downwards.

Et voilà!
Repeat with the other side.

INSTALL YOUR VTX SLIDER

INSTALL THE SQUARE NUT

SCREW IN !

WALKSNAIL
20x20
use the shorter M2 screws
provided with your vtx

DJI O3
25x25
use our M1.6/8mm screws
preferably on the flat side of
the vtx

OTHERS
you're on your own,
we trust you !

ANTENNA ←

→ CAMERA

INSTALL YOUR VTX SLIDER


8MM + WASHER

in the right direction, insert the bottom of the vtx slider into the slot.

screw in with a 8mm screw with washer

choose the position and squeeze

ET VOILÀ !

8MM

10MM
+ WASHER

MERCI.